

# Truck Scales



**Delivery and Installation**  
of Vehicle Scales

**The Most Experienced**  
Vehicle Scale Installers in the World

**METTLER TOLEDO**

# Certified Driver/Scale Technicians Install METTLER TOLEDO Vehicle Scales

## One-Stop Installation

METTLER TOLEDO's unique truck scale delivery vehicles can save you time and money while making your truck scale installation go smoothly. Our drivers are factory-trained technicians, fully qualified and equipped to install your scale. They have done it hundreds of times, and you benefit by their experience. The trucks are equipped with a specially designed crane that sets the scale quickly. There is no need for you to rent and schedule a crane from a third party.

Typically installation can be done in one day from the time the truck pulls up to the foundation. Base plates are set, modules anchored in place and electrical connections are made, and all with the efficiency that only experience



brings. Thousands of vehicle scales have been delivered and installed using this exclusive METTLER TOLEDO service.

## Installation Procedure

1. Delivery truck pulls up next to the foundation.
2. Unload and place the base plates.
3. Unload each module with the built-in crane.
4. Anchor modules in place.
5. Load cells are installed.
6. Scale is electrically connected and calibrated.

After your installation is complete, your METTLER TOLEDO certified technician can test, calibrate and certify your scale. Through our nationwide network of certified service offices, we have a fleet of test trucks available to service truck, rail, hopper/tank, floor, and other heavy-capacity scales, normally within 24 hours.

Contact your nearest METTLER TOLEDO office or authorized distributor for all the details.

**Mettler-Toledo, Inc.**  
1900 Polaris Parkway  
Columbus, Ohio 43240  
Tel. (800) 523-5123  
(614) 438-4511  
Fax (614) 438-4900

Specifications subject to change without notice.  
© 2006 Mettler-Toledo, Inc.  
Printed in USA.

5M0206  
I99-TR03192.1E

1



2



3



4



5



6



[www.mt.com](http://www.mt.com)

For more information